

Pretreatment Guide with Mister T1 Machine and EcoFreeen Pretreatment

	Slow <- Speed -> Fast				
	More <- Volume -> Less				
Uni-direction spray	1	2	3	4	5
	Light Color thick	Light Color Thin	White thick shirts	White medium shirts	White Thin shirts
	0.08125ml/sq.in	0.071875ml/sq.in	0.059375ml/sq.in	0.053125ml/sq.in	0.04375ml/sq.in
Bi-direction spray	1	2	3	4	5
	Hoodies	Black Super Thick	Black Thick	Black Medium	Black Thin
	0.1625ml/sq.in	0.134375ml/sq.in	0.1125ml/sq.in	0.09375ml/sq.in	0.078125ml/sq.in

For other pretreatment fluids, some minor adjustments may be needed

\